

CERTINA

Renvoi
Setting wheel
Rueda de transmisión
Zeigerstellrad
Rinvio



450

Calibre de base Basic calibre Calibre de base Grundkaliber Calibro di base	Valable pour les calibres Applicable for the calibres Válido para los calibres Verwendbar für die Kaliber Adoperabile per i calibri	Observations Remarks Observaciones Bemerkungen Osservazioni
230	258, 258 SC, 15-10, 15-14	
240		
251		
260	261, 262, 263	
270	271, 275	
300	301, 304, 320, 320 T, 321, 321 T, 324, 324 T, 410, 411, 414	
330	331	
400	401, 404	
12-10	370, 12-11	
13-10	248, 13-11	
13-20	13-21, 13-22	
13-50		
13-51		
15-20	15-21, 17-211, 17-221	
17-10	350, 351, 17-11, 17-12	
17-25	17-251	
17-351	17-36, 17-361	
19-10	340, 340 T, 341, 341 T, 344, 344 T, 19-11, 19-12, 19-14	
19-25	19-251, 19-26, 19-35, 19-351, 19-36, 19-45, 19-451, 19-55, 19-551	
19-30	19-31	
23-20		
23-30		
23-35	23-36, 25-35, 25-36, 25-45, 25-451, 28-45, 28-451	
25-65	25-651, 25-652, 25-66, 25-661, 25-681, 25-682	*
28-10	28-102	
28-15	28-151, 28-16, 28-161	