






















































	N°	English
	7878	Click
	7879	Screw for click
	7880	Click spring
	7881	Setting-lever
	7882	Screw for setting-lever
	7883	Setting-lever jumper
	7885	Yoke for sliding pinion
	7885-1	Yoke stud
	7886	Yoke spring
	7887	Setting-wheel
	7887-7	Ring for setting-wheel stud
	7888	Minute wheel
	7888-1	Minute wheel stud

	N°	English
	7889	Cannon pinion ht. 2.23mm
 	7890	Hour wheel
	7891	Friction-spring for hour wheel
	7892	Dial screw
	7896	Screw for case head bevelled
	7897	Screw for case head flat
	7898	Set of screws
	7900	Automatic device bridge, upper
	7901	Automatic device lower bridge
	7902	Screw for Automatic device bridge, upper

	N°	English
	7903	Oscillating weight
	7904	Automatic device module
	7905	Screw for automatic device lower bridge
	7906	Axle for oscillating weight
	7907	Jewel for oscillating weight-upper
	7909	Jewel for oscillating weight-lower
	7910	Pinion for oscillating weight
	7911	Spring-clip for oscillating weight
	7912	Reversing wheel, mounted
	7912-1	Driver, only

	N°	English
	7913	Jewel for reversing wheel-upper /lower
 	7917	Driving wheel for ratchet wheel
	7918	Jewel for driving wheel for ratchet wheel-upper
	7919	Jewel for driving wheel for ratchet wheel-lower
	7920	Bush for barrel-upper
 	7930	Shock absorber for balance-upper
 	7931	Shock absorber for balance-lower
	7932	In-setting for balance-upper / lower
	7934	In-setting spring for balance-upper
	7936	In-setting for escape wheel 26 jewels-upper /lower
	7937	Cap jewel for escape wheel-upper /lower
	7938	In-setting spring for escape wheel-upper /lower

	N°	Idem calibre	English
	8075		Main plate
	8076		Bush for centre wheel-lower
	55003	3035	Screw for setting-lever jumper
	95019-3	3035	Cap jewel for balance-upper / lower
	95019-4	3035	In-setting spring for balance- upper /lower