















Calibre 1575














Ø28.50mm
Ht: 6.30mm
Train: 19.800









- Automatic
- Calendar
- Centre Seconds
- Shock Proof
- 26 Jewels



Base Calibre 1530

| Image | Rolex No. | Description |
|---|-----------|---|
|  | 5093 | Calendar wheel nut |
|  | 7950 | Centre wheel with cannon pinion |
|  | 7951 | Cannon pinion ht. 2.75mm |
|  | 7952 | Hour wheel with double tothing |
|  | 7955 | Date jumper |
|  | 7956 | Date indicator seating, ref 1500, 1501, 1503 |
|  | 7957 | Screw for date jumper |

| Image | Rolex No. | Description |
|--|-----------|---|
|  | 7958 | Stud for date indicator seating |
|  | 7959 | Jewel for stud |
|  | 7960 | Screw for date indicator seating |
|  | | Date indicator: |
| | 7961-1 | champagne |
| | 7961-2 | silvered |
|  | | Date indicator: |
| | 7961-101 | champagne, arabic |
| | 7961-201 | silvered, arabic |
|  | 7963 | Date indicator seating, Ø ext. 27.86mm ref. 1600, 1601, 1602, 1603, 1605 |
|  | 7964 | Date indicator seating, Ø ext. 27.20mm ref. 1625 |

| Image | Rolex No. | Description |
|---|-----------|----------------------------------|
|  | 7978 | Screw for stud holder |
|  | 7981 | Screw for regulating the balance |
|  | 8006 | Yoke for cam |
|  | 8007 | Jewel for yoke for cam |
|  | 8008 | Spring for cam yoke |
|  | 8011 | Stud for cam |
|  | 8021 | Date wheel, mounted |
|  | 8050 | Second wheel |
|  | 8051 | Escape wheel, 26 jewels |
|  | 8065 | Shock-absorber for balance-upper |
|  | 8074 | Screw for balance stop spring |
|  | 8076 | Bush for center wheel-lower |
|  | 8102 | Balance bridge |

| Image | Rolex No. | Description |
|---|-----------|--|
|  | 8103 | Stud support with small plate |
|  | 8106 | Balance with Breguet hairspring, timed |
|  | 8108 | Screw for balance |
|  | 8109 | Automatic device upper bridge |
|  | 8110 | Automatic device module |
|  | 8112 | Set of screws |
|  | 8115 | Balance stop spring |
|  | 8119 | Main plate |

| Image | Rolex No. | Description |
|---|---|--|
|  | <p style="text-align: center;">8131</p> | <p>Date indicator seating, Ø 29.46mm ref. 1530, 1630</p> |
| <p style="text-align: center;">i</p> | <p style="text-align: center;">55051</p> | <p>Screw for stud</p> |
|  | <p style="text-align: center;">95098</p> | <p>Roller for date indicator seating</p> |
| | | |