




Calibre No.	<h1>5621A</h1>	Jewels	<h1>25j</h1>
⇒ Basic Calibre 5606A <sup>23J</sup> / <sub>25J</sub> Catalog No. 56-06-1			



Cal. 5621A

### Characteristics

- Casing diameter: 25.60  $\phi$  mm
- Maximum height: 4.50 mm
- Vibrations per hour: 28,800
- Automatic and auxiliary hand winding with sweep second
- Second-setting device
- Outside micro-adjusting device
- "Diashock" Shock Resistant Device
- "Diafix" Oil Lubrication Device



112561



171561



401565



251561



301561



310561



341561



344561



793561



285561



387561



388562




391561



509566



808561



Calibre No. <b>5621A</b>		Jewels <b>25j</b>	Style Name	
⇒ Basic Calibre <b>5606A</b> <sup>23J</sup> / <sub>25J</sub> Catalog No. 56-06-1				
PART NO.	LIST OF MATERIALS	PART NO.	LIST OF MATERIALS	
<b>112561</b>	<b>Barrel &amp; train-wheel bridge</b>	022257	Yoke spring screw (Clutch lever spring screw)	
161560	Pallet cock	022373	Pallet cock screw	
<b>171561</b>	<b>Balance cock</b>	022454	Screw for reverser idler bolt	
189560	Transmission wheel bridge	<b>022457</b>	<b>Yoke screw (Clutch lever screw)</b>	
205560	Complete barrel with arbor	022458	Screw for oscillating weight	
213560	Barrel arbor	022467	Ratchet wheel screw	
220560	Large driving wheel & pinions	022484	Bridge screw	
225560	Cannon pinion	022486	Minute wheel bridge screw	
231560	Third wheel & pinion	022662	Setting lever spring screw	
241560	Sweep second wheel & pinion	022667	Second-setting lever screw	
<b>251561</b>	<b>Escape wheel &amp; pinion</b>	022753	Date dial guard screw	
261560	Minute wheel	022761	Dial screw	
271611	Hour wheel	011123	Upper hole jewel for barrel	
282560	Clutch wheel	011142	Lower hole jewel for barrel	
283560	Winding pinion	011147	Upper hole jewel for large driving wheel & pinions	
<b>285561</b>	<b>Ratchet wheel</b>	011147	Lower hole jewel for large driving wheel & pinions	
<b>301561</b>	<b>Jewelled pallet fork &amp; staff</b>	011323	Lower hole jewel for 3rd wheel	
<b>310561</b>	<b>Balance complete with stud</b>	011423	Lower hole jewel for escape wheel	
315560	Balance staff	011503	Upper hole jewel for pallet	
331560	Roller with jewel	011503	Lower hole jewel for pallet	
<b>341561</b>	<b>Regulator</b>	011159	Upper hole jewel for transmission wheel	
<b>344561</b>	<b>Regulator adjusting device</b>	011159	Lower hole jewel for transmission wheel	
345612	Stud holder	011151	Upper hole jewel for differential wheel	
354560	Winding stem	011133	Lower hole jewel for differential wheel	
361560	Second-setting lever spring	011147	Lower hole jewel for 1st reverser idler	
367560	Minute wheel spring	023179	Tube for minute wheel bridge screw	
381560	Click	023180	Tube for bridge screw (Cylinder type)	
☆383560	Setting lever	023184	Tube for bridge screw (Recessed type)	
☆383561				
☆383562				
384560	Yoke (Clutch lever)			
385560	Yoke spring (Clutch lever spring)			
<b>387561</b>	<b>Minute wheel bridge</b>			
<b>388562</b>	<b>Setting lever spring</b>			
390560	Setting lever axle			
<b>391561</b>	<b>Second-setting lever</b>			
<b>401565</b>	<b>Mainspring with slipping attachment</b>			
<b>793561</b>	<b>Micro-adjusting axle</b>			
014363	Diashock upper frame			
014384	Diashock lower frame			
014365	Diashock hole jewel with frame			
011210	Diashock cap jewel			
014317	Diashock spring			
015421	Diafix upper hole jewel with frame for 3rd wheel			
015411	Diafix upper hole jewel with frame for escape wheel			
011206	Diafix cap jewel			
015113	Diafix spring			
<b>509566</b>	<b>Oscillating weight with ball-bearing</b>			
505560	Transmission wheel			
531560	Differential wheel			
848560	First reverser idler			
851560	Second reverser idler			
854560	Reverser idler bolt			
803560	Setting wheel lever complete			
<b>808561</b>	<b>Date dial guard</b>			
812560	Setting wheel lever spring			
☆884560	Holding ring for dial			
022150	Stud screw			
022252	Transmission wheel bridge screw			

☆⇒ Please see remarks on the next page.

Items in light letters are not shown in photos; those parts are interchangeable with the basic calibre

(Cal. No. **5606A** <sup>23J</sup>/<sub>25J</sub> Catalog No. 56-06-1 Green page).

Calibre No. <b>5621A</b>	Jewels <b>25j</b>	Style Name
⇒ Basic Calibre 5606A <sup>23J</sup> / <sub>25J</sub> Catalog No. 56-06-1		

**Remarks :**

**Setting lever**

There are three types of setting levers, used according to the dial diameter. Select the suitable setting lever by referring to the shapes indicated in the photos and fig. 1.

When a setting lever unsuitable for the dial diameter is used, the winding stem cannot be pulled out or the movement cannot be assembled in the case. Pay attention to this point (refer to fig. 2).

When the dial is round, the number of the setting lever differs (listed below) according to the dial diameter.

- (Dial diameter) 25.5~26.5φmm..... ☆ 383561
- ( " ) 27.5~28.5φmm..... ☆ 383560
- ( " ) 29.5~30.5φmm..... ☆ 383562

If the number of the setting lever is unknown or when placing an order for a setting lever other those mentioned above, specify ① Cal. No. and ② the dial No.

[fig. 1]



☆ 383560




☆ 383561



☆ 383562


[fig. 2]

When the setting lever is too small




Setting lever is hidden under the dial and the winding stem cannot be pulled out.

When the setting lever is too large



Blocked by the setting lever, the movement cannot be assembled in the case.

Correct



End of the setting lever is located between the dial and the case.

**Holding ring for dial** ——— Measure the total thickness and the outside diameter ———

☆ 884560 .....0.53mm total thickness and 27.0φmm outside diameter.

If the holding ring for dial is required in any other type, specify ① Cal.No. and ② the dial No.